



- 5nA
- 520nA
- 24nA
- 124nA
- 29nA
- 12nA
- 714nA

- With 48V and 390k:
- 5nA
 - 133nA
 - 24nA
 - 65nA
 - 23nA
 - 6nA
 -
 - 256 nA

They say in datasheet $2r_e=32$ Ohm that's re 16 Ohm. 26 Ohm is at 1mA so the I_e in the transistors inside is 1.6mA. Assuming gain of 100, the I_b is 16uA. This makes 1.3nA at the input @ 10 MHz, totally negligible.

They say in datasheet $2r_e=32$ Ohm that's re 16 Ohm. 26 Ohm is at 1mA so the I_e in the transistors inside is 1.6mA. Assuming gain of 100, the I_b is 16uA. This makes 1.3nA at the input @ 10 MHz, totally negligible.

- With 48V and 390k:
- 5nA
 - 133nA
 - 24nA
 - 65nA
 - 23nA
 - 6nA
 -
 - 256 nA

Ronja RX Noise

TITLE	Ronja RX Noise		REVISION:	20081028
FILE:	licensed under GFDL		DRAWN BY:	Clock
PAGE	1	OF	1	