



A1 Gnuicap directive .include sim/models/bf199.lib

A2 Gnuicap directive .include sim/models/bfr91a_worst.lib

A3 Gnuicap directive .include sim/models/bfr91a_best.lib

A4 Gnuicap directive .include sim/models/bfr90.lib

A5 Gnuicap directive .include sim/models/bfr91.lib

A6 Gnuicap options numdgt=9 out=10000 clobber norstray

A7 Gnuicap directive .print ac zm(me1) zr(me1) zi(me1) zm(me2) zr(me2) zi(me2) zm(me3) zr(me3) zi(me3) zm(me4) zr(me4) zi(me4) zm(me5) zr(me5) zi(me5)

A8 Gnuicap directive .op

A9 Gnuicap directive .ac 1k 100Meg Dec 20 >sim/199_cap.data Basic Quiet

BF199 and BFR91A Worst Case Emitter Capacity

TITLE

FILE: To be released under GFDL

REVISION:

PAGE 1 OF 1

DRAWN BY: Clock