



```

A1  Gnuicap directive  .include sim/models/bf199.lib
A2  Gnuicap directive  .include sim/models/bfr91a_worst.lib
A3  Gnuicap directive  .include sim/models/bfr91a_best.lib
A4  Gnuicap directive  .include sim/models/bfr90.lib
A5  Gnuicap directive  .include sim/models/bfr91.lib
A6  Gnuicap options    numdgt=9 out=10000 clobber norstray
A7  Gnuicap directive  .print ac zm(me1) zr(me1) zi(me1) zm(me2) zr(me2) zi(me2) zm(me3) zr(me3) zi(me3) zm(me4) zr(me4) zi(me4) zm(me5) zr(me5) zi(me5)
A8  Gnuicap directive  .op
A9  Gnuicap directive  .ac 1k 100Meg Dec 20 >sim/199_cap.data Basic Quiet
  
```

BF199 and BFR91A Worst Case Emitter Capacity

TITLE		BF199 and BFR91A Worst Case Emitter Capacity	
FILE:	To be released under GFDL	REVISION:	
PAGE	1 OF 1	DRAWN BY:	Clock