

```

A1 Gnuicap directive .include sim/models/bfr90_worst.lib
A2 Gnuicap directive .include sim/models/bfr91_worst.lib
A3 Gnuicap directive .include sim/models/bfr91_best.lib
A4 Gnuicap directive .include sim/models/bfr91a_worst.lib
A5 Gnuicap directive .include sim/models/bfr91a_best.lib
A6 Gnuicap options numdgt=9 out=10000 clobber nstray
A7 Gnuicap directive .print ac z:(V1) z:(V3) z:(V5) z:(V7) z:(V9)
A8 Gnuicap directive .op
A9 Gnuicap directive .ac 11k 9.5G Dec 100 >sim/current.data Basic Quiet
A10 Gnuicap directive .include sim/models/bfr90_best.lib

```

Current Source Output Impedance			
TITLE			
FILE	To be released under GFDL	REVISION	20091007
PAGE	1 OF 1	DRAWN BY	Click