



120k noise

307=560 in parallel with 680.  
560 is the default from the old RX schematic.  
Produces noise on the negative input of the video amp.  
473uA from the NE592 input

2.2M noise

25 Ohm noise

```

A1  Gnuicap directive  .include sim/models/bf90_worst.lib
A10 Gnuicap directive  .include sim/models/bf90_best.lib
A2  Gnuicap directive  .include sim/models/bf91_worst.lib
A3  Gnuicap directive  .include sim/models/bf91_best.lib
A4  Gnuicap directive  .include sim/models/bf91a_worst.lib
A5  Gnuicap directive  .include sim/models/bf91a_best.lib
A6  Gnuicap options    numdgt=9 out=10000 clobber rstray
A7  Gnuicap directive  .op
A8  Gnuicap directive  .print ac im(G1) im(G2) im(G3)
A9  Gnuicap directive  .ac 1Meg 10Meg *10 >sim/fe.data Basic Quiet
  
```

# Frontend with DIY Coil

TITLE	Frontend with DIY Coil	
FILE:	To be released under GFDL	REVISION: 20090131
PAGE	1 OF 1	DRAWN BY: Clock