



```

A1 Gnuicap directive .include sim/models/bfr90_worst.lib
A2 Gnuicap options numdgt=9 out=10000 clobber=stay
A3 Gnuicap directive .print tran (i1) v(i1) (v5) (v6) (v9) (v10) (v13) v(R1) v(R11) v(R20) v(R21) v(R29)
A4 Gnuicap directive .op
A5 Gnuicap directive .transient 0 1u 100p skip 10 >sim/tran90.data Basic Quiet

```

TITLE			
BFR90 transient response		REVISION:	
FILE	Licensed under GFDL	20081024	
PAGE	1	OF	1
DRAWN BY:		Clock	