



```

A1 Gnuicap directive .include sim\models\bfr91a_worst.lib
A2 Gnuicap options numdgt=9 out=10000 clobber rstray
A3 Gnuicap directive .print tran (i1) v(i1) ic(q3) ic(q4) ic(q6) ic(q7) ic(q9) V(R1) V(R11) V(R12) V(R20) V(R21) V(R29) V(rs1) V(rs2) V(rs3))
A4 Gnuicap directive .op
A5 Gnuicap directive .transient 0 1u 100p skip 10 >sim\tran91a.data Basic Quiet

```

TITLE					
FILE	Released under GFDL		REVISION	20081025	
PAGE	1	OF	1	DRAWN BY	Click