

A1	Gnucap directive	include sim/models/bh90_wand.lib
A10	Gnucap directive	include sim/models/bh90_band.lib
A11	Gnucap directive	include sim/models/bh97_wand.lib
A12	Gnucap directive	include sim/models/bh97_band.lib
A1	Gnucap directive	include sim/models/bh97a_wand.lib
A2	Gnucap directive	include sim/models/bh97a_band.lib
A3	Gnucap options	numdgt=8 out=10000 shlibver=ngnug
A5	Gnucap directive	op
A6	Gnucap directive	print ac tmdb(C3) tmdb(C4) vp(C3) vp(C4)
A7	Gnucap directive	dc 17k 9.5G Dev 5G -c sim/fet.data Basic Quiet
A8	Gnucap directive	print ac tmc(C2) tmc(C3) tmc(C4) tmc(C5)
A9	Gnucap directive	dc 100meg -c sim/fet2.data Basic Quiet

Coil Frontend

TITLE			
FILE	To be released under GPL	REVISION	20081102
PAGE	1 of 1	DRAWN BY	Chick