


| | | |
|---|---|---|
| A1 | Gnucap directive | include sim/models/bf490_word.lib |
| A10 | Gnucap directive | include sim/models/bf490_best.lib |
| A11 | Gnucap directive | include sim/models/bf491_word.lib |
| A12 | Gnucap directive | include sim/models/bf491_best.lib |
| A2 | Gnucap directive | include sim/models/bf491a_word.lib |
| A3 | Gnucap directive | include sim/models/bf491a_best.lib |
| A4 | Gnucap options | noredirg-8 out=10000 clobber noisy |
| A5 | Gnucap directive | op |
| A6 | Gnucap directive | print ac mode(50) vm(50) vp(50) vp(10) |
| A7 | Gnucap directive | ac 11 9.0G Dec 50 >sim/field.data Basic Quiet |
| A8 | Gnucap directive | print ac vm(51) vp(51) vm(510) vp(510) vm(57) vm(53) |
| A9 | Gnucap directive | ac 1Meg 100Meg *10 >sim/field2.data Basic Quiet |

# Frontend with DIY Coil

| | | | | | |
|---|---|---|---|---|---|
| Title | | | | | |
| File | To be released under GPSL | | | Revision | 20090101 |
| Page | 1 | of | 1 | Modified by | Chuck |