
39dp alone ~0.75dB @1MHz
15n alone ~0.75dB @1MHz
BFR91A_worst
BFR91A_best
generator(1)
A1 Gnucap directive include sim/models/bfr90_worst.lib
A10 Gnucap directive include sim/models/bfr90_best.lib
A11 Gnucap directive include sim/models/bfr91_worst.lib
A12 Gnucap directive include sim/models/bfr91_best.lib
A2 Gnucap directive include sim/models/bfr91a_worst.lib
A3 Gnucap directive include sim/models/bfr91a_best.lib
A4 Gnucap options numdgt=9 out=10000 clobber noray
A5 Gnucap directive .op
A6 Gnucap directive print ac im(ib(L2) im(ib(L97) ip(L2) ip(L97)
A7 Gnucap directive .ac 1 fs 9 SG Dec 50 +sim/stage1.data Basic Quiet
A8 Gnucap directive print ac im(L2) im(L6) im(L90) im(L86)
A9 Gnucap directive .ac 1Meg 10Meg *10 +sim/stage12.data Basic Quiet