

A1	Gnuicap directive	.include sim/models/bfr90_worst.lib
A2	Gnuicap directive	.include sim/models/bfr91_worst.lib
A3	Gnuicap directive	.include sim/models/bfr91_best.lib
A4	Gnuicap directive	.include sim/models/bfr91a_worst.lib
A5	Gnuicap directive	.include sim/models/bfr91a_best.lib
A6	Gnuicap options	numdgt=9 out=10000 cltobber rstray
A7	Gnuicap directive	.print ac zr(V1) zr(V3) zm(V1) zm(V3) zm(V5) zm(V7) zm(V9)
A8	Gnuicap directive	.op
A9	Gnuicap directive	.ac 11k 9.5G Dec 100 >sim/current.data Basic Quiet
A10	Gnuicap directive	.include sim/models/bfr90_best.lib

<b>Current Source Output Impedance</b>	
TITLE	
FILE	To be released under GFDL
REVISION:	20081007
PAGE	1 OF 1
DRAWN BY:	Clock

